

## INSTALLATION INSTRUCTIONS

- 1.) Look over the mat before you start. Check that the thickness is 2", and the mats are 4'x6' in size. Also, look at the corrugated bottom of the mat which helps anchor the mat in place and aids in channeling water runoff.**
- 2.) Excavate an area 4'x6' in size x6" deep for each mat you are installing.**
- 3.) After step 2 is done, fill the bottom of the excavation with a 4" depth of pea gravel or crushed stone. Make sure the gravel is level throughout the 4'x6' area.**
- 4.) Next, install a single layer of TYPAR, or other approved geotextile fabric, over the gravel to keep out weeds and preventing debris from filtering down to the gravel.**
- 5.) Place a DYNACUSHION 4'x6' mat over the TYPAR fabric, making sure the top of the mat is level with grade, and is level.**
- 6.) Cover mat with your choice of loose fill safety surfacing material.**

**NOTE: For a stand alone surface the top surface of the DYNACUSHION should be level with surrounding surface. Stand alone surface meaning no loose fill will be used on top surface of mat.**

**DYNACUSHION playmats must be coated with ULTRASEAL when being used as a stand alone surfacing material, which can be done during manufacturing.**